


ACCESSORIES AND PARTS For CATCO Catalytic Heaters

GENERAL DESCRIPTION

CATCO provides various parts and accessories for use with catalytic heaters. All parts and accessories are designed to enhance the effectiveness and, in some cases, the safe operation of catalytic heaters.

Definitions and Explanations

- Wall Brackets are used to mount a heater directly to a wall or bulkhead.
- **Pigtails** are used to make heater startups easier by having a "built in" power cable. 12 volt pigtails are equipped with battery clamp ends, while 120 volt pigtails are equipped with a standard 3 prong male wall plug.
- Thermocouples operate in conjunction with the safety valves. If the heater stops operating, the thermocouple allows the safety valve to close.
- Turndown Valves allow for manual reduction of heater output by 50%. Heater size must be specified.
- **Thermostats** automatically reduce heater output by 50% when the



Explosion Proof Junction Box

Availability


Most parts and accessories are kept in stock and can usually be shipped same or next day.

- **Dual Heater Manifolds** allow for enclosure packages with two heaters to be plumbed into one regulator.
- Safety Valves shut off the gas supply to the heater, should the heaters stop operating.
- desired temperature is reached. Heater size must be specified.
- **Reflectors** help to direct radiant heat.

Accessories

WALL BRACKETS

| Part No. | Description |
|----------|------------------------------------|
| 10-005 | For 66, 88, 1012 Heaters, Pair |
| 10-010 | For 1212, 624, 1224 Heaters, Pair |
| 10-011 | For 1230, 1246 Heaters, Pair |
| 10-015 | For 1836, 1848, 1560 Heaters, Pair |
| 10-017 | For 2448, 2460 Heaters, Pair |



ELECTRICAL ACCESSORIES

| Part No. | Description |
|----------|---|
| 20-005 | Explosion Proof Junction Box, Single 1/2" NPT Outlet |
| 20-006 | Explosion Proof Junction Box, Dual 1/2" NPT Outlet |
| 20-010 | Explosion Proof Junction Box, Single 3/4" NPT Outlet |
| 20-020 | 16' Pigtail, 14-2 Cord, for Standard Junction Box, 12V Heater |
| 20-021 | 16' Pigtail, 14-2 Cord, for Explosion Proof Junction Box, 12V Heater |
| 20-022 | 16' Pigtail, 14-2 Cord, for Standard Junction Box, 120V Heater |
| 20-023 | 16' Pigtail, 14-2 Cord, for Explosion Proof Junction Box, 120V Heater |
| 20-027 | 16' Pigtail, 8-3 Cord, for Explosion Proof Junction Box, 12/120V Heater |



REGULATORS AND MANIFOLDS

| Part No. | Description |
|----------|---|
| 50-005 | Fisher 912/194, 250 psi inlet, 4.5" WC out, 1/4" NPT Connection |
| 50-010 | Fisher 912/194, 250 psi inlet, 11" WC out, 1/4" NPT Connection |
| 50-015 | Fisher 532, 250 psi inlet, 4.5" WC out, 1/2" NPT Connection |
| 50-016 | Fisher 532, 250 psi inlet, 11" WC out, 1/2" NPT Connection |
| 50-025 | Fisher 67, 250 psi inlet, 1/4" NPT Connection |
| 50-030 | Fisher 67 AFR, 250 psi inlet, 1/4" NPT Connection |
| 50-035 | MECO Type P, 6000 psi inlet, 1/4" NPT Connection |
| 50-040 | Fisher 1301F, 6000 psi inlet, 1/4" NPT Connection |
| 55-010ST | Dual Heater Manifold, Steel Fittings, With Fisher 912/194 Regulator |
| 55-010SS | Dual Heater Manifold, SS Fittings, With Fisher 912/194 Regulator |



VALVES AND THERMOSTATS

| TALTES AIT | DITIERWOSIAIS |
|------------|---|
| Part No. | Description |
| 30-006 | Safety Valve (Replacement Part) |
| 30-010 | Thermocouple (Replacement Part) |
| 30-030 | Turndown Valve, 1/4" NPT Connection (specify heater size) |
| 30-035 | Ball Valve, Bronze, 1/4" NPT Connection |
| 30-035SS | Ball Valve, Stainless Steel, 1/4" NPT Connection |
| 30-050 | Check Valve, Brass, 50 psi (relief valve) |
| 30-050SS | Relief Valve, SS, NUPRO, 50 psi |
| 40-005 | Thermostat, Honeywell, 1/4" NPT, 60-100 F (specify heater size) |
| 40-010 | Thermostat, Honeywell, 1/2" NPT, 60-100 F (specify heater size) |
| 40-020 | Thermostat, Honeywell, 1" NPT, 60-100 F (specify heater size) |
| 40-030 | Thermostat, Robertshaw, 1/4" NPT, 60-250 F° (specify heater size) |
| | |





FACE GRILLES AND REFLECTORS

| Part No. | Description | |
|----------|--------------------------------|--|
| 60-001 | Face Grille, 624 Heater | |
| 60-002 | Face Grille, 1212 Heater | |
| 60-003 | Face Grille, 1224 Heater | |
| 60-004 | Face Grille, 1236 Heater | |
| 60-005 | Face Grille, 1248 Heater | |
| 60-006 | Face Grille, 2448 Heater | |
| 60-007 | Face Grille, 1836 Heater | |
| 60-008 | 60-009 Face Grille, 612 Heater | |
| 61-020SS | Reflector, 624 Heater | |
| 60-021SS | Reflector, 1212 Heater | |
| 61-022SS | Reflector, 1224 Heater | |
| 61-023SS | Reflector, 1236 Heater | |
| 61-024SS | Reflector, 1248 Heater | |
| 61-030SS | Reflector, 2460 Heater | |

